WAVLINK®

QUICK START GUIDE

AC1200 Dual Band Gigabit Wi-Fi Router

WAVLINK (@WavlinkOfficial)
WAVLINK SUPPORT (@WavlinkTechSupport)
For installation video, please visit:
https://www.youtube.com/c/WavlinkOfficial

Aerial G2

OVERVIEW

1. 4 x 10/100Mbps LAN ports
2. Gigabit WAN port
3. WPS/Reset Button
4. Power port

WPS Button:
Press and hold for 1 ~ 2 seconds.

Reset Button:
Press and hold for 6 seconds to reset the device.

LED Indication

LED	Description
Pink on	The device is being activated.
Solid blue	The Internet is connected.
Blue flash	The router WPS is trying to connect to the network adapter of your PC.
Red flash	The device is disconnected.

BASIC INFO

Default IP: 192.168.10.1
Login URL: wifi.wavlink.com
2.4G SSID: WAVLINK-N
5G SSID: WAVLINK-AC
Default password: admin
Official Website: www.wavlink.com
Technical support: support@wavlink.com

In the box

- 1 x AC1200 dual band Gigabit router
- 1 x Ethernet cable
- 1 x Power adapter
- 1 x Quick start guide

Device Setup

1. Connect **WAN** port of the device to the modem or LAN port of an upstream router, then plug it in a power outlet.

2. Connection

2.1 **Via Wireless**

Turn on your Wi-Fi, search SSID "**WAVLINK-N**" or "**WAVLINK-AC**", and connect to it; then you can start configuring.

For Windows users　　For Mac users

2.2 **Via Cable**

Connect **LAN** port of the device to your laptop, then you can start configuring.

3. Launch a browser from your laptop/PC or smart phone and enter wifi.wavlink.com or 192.168.10.1 in the address field. The default password is **admin**.

4. For your network security, we suggest you create a new login password, next time when you log in, you need to use your new password.

5. Please select the mode fit for your own need.

6. Select the **WAN Type** according to the type of your network.

Which WAN Type am I supposed to choose?

If you use DSL line and you are only provided an account name and a password by your ISP, choose **PPPoE**. If you use cable TV or fiber cable, choose **DHCP(Dynamic IP)**. If you are provided information such as IP address, Subnet Mask and Default Gateway, choose **Static IP**.

Remark:

If you are not sure about your Internet type, please contact your Internet Service Provider (ISP); your ISP generally offers you all necessary information when your Internet service is activated.

7. The default 2.4G and 5G SSID are "WAVLINK-N" and "WAVLINK-AC", you can use the default SSIDs or create your own ones.

2.4G SSID	WAVLINK-N
5G SSID	WAVLINK-AC

8. If you use WISP mode, please follow the steps below:

1) Log in to 192.168.10.1 or wifi.wavlink.com;
2) Select "Wizard" and click on "WISP" mode.
3) Choose one of host routers on the list, then enter its password(s).
4) Or you can manually fill out the host router information.

FIRMWARE UPGRADE

If you need to update firmware, please proceed as the following steps:

1. Download the latest firmware file on Wavlink website.
2. Extract the firmware from the downloaded file.
3. Log in to 192.168.10.1 or wifi.wavlink.com, then choose "**Setup**" and select "**Upgrade Firmware**".

4. Click on **Browse** to locate the extracted firmware file.
5. Click on **Apply**, and wait for the firmware upgrade process to complete.

What is firmware upgrade and why do I need it?

Firmware contains fixes for bugs and new features, please keep the latest firmware to improve the experience of using the product. Please do not use the wrong firmware, otherwise, it will damage your device and void the product warranty.

For more details, please visit our website www.wavlink.com
Our Technical Support: **support@wavlink.com**

Change login password

If you need to reset the login password, please follow steps below:

1. Log in to "wifi.wavlink.com" or "192.168.10.1".
2. Click "Setup" --> "Login Password".
3. Enter the old password, then enter the new password (case-sensitive) and click on "Apply" button to confirm.

Wi-Fi Password Configuration

If you need to create new passwords or change Wi-Fi passwords, you can check the following steps for reference:

1. Click "**Wi-Fi**" > "**Wi-Fi Configuration**".
2. Now please set/reset your passwords and click on "Apply" to confirm.

Attention:
If you cannot configure the network on your android phone, we suggest that you turn off your 4G signal first before network setup, then turn it on after the configuration is done.

FAQ

Q1. Why doesn't the login page appear after entering http://wifi.wavlink.com?
- Make sure your PC is set to obtain IP address automatically.
- Please make sure you entered the correct website.
- Reboot your device and try again.

Q2. What can I do if I can not access the Internet?
- Make sure your Internet works normally, please contact your **ISP**(Internet Service Provider) if it doesn't.
- Initiate your browser, enter 192.168.10.1 or wifi.wavlink.com, then set up following the quick start guide.
- Reboot your device and try again.

Q3. How do I restore the device to factory default setting?
- Press and hold the reset button of the device for 6 seconds.

Q4. What can I do if I forget my administration management password?
- Please reset the device, the default password is **admin**.

Q5. How do I find the best location for my device?
- Please put your device in a relatively open space to avoid obstacles such as metal objects, reinforced concrete walls and so on.

Q6. What should I do if I can't have access to 192.168.10.1 or wifi.wavlink.com on my android phone?
- We suggest you turn off your 4G signal first before you set up the network, then turn it on when the configuration is done.

Please visit https://www.wavlink.com/en_us/faq.html for more details.

GNU GENERAL PUBLIC LICENSE NOTICE

This product includes software codes developed by third parties. These software codes are subject to either the GNU General Public License (GPL), Version 2, June 1991 or the GNU Lesser General Public License (LGPL), Version 2.1, February 1999. You can copy, distribute, and/or modify in accordance with the terms and conditions of GPL or LGPL.
The source code should be complete, if you want us to provide any additional source code files under GNU General Public License (GPL), please contact us in these matters. We are committed to meeting the requirements of the GNU General Public License (GPL). You are welcome to contact us local office to get the corresponding software and licenses. Please inform us your contact details (full address) and the product code. We will send you a software package with the software and license for free.
The respective programs are distributed WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.
Please refer to the GNU General Public License website for further information.
http://www.gnu.org/licenses/old-licenses/lgpl-2.0.html
http://www.gnu.org/licenses/gpl.html

WEEE Directive & Product Disposal

At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

Thanks for purchasing WAVLINK product!

WAVLINK (@WavlinkOfficial)
WAVLINK SUPPORT (@WavlinkTechSupport)
For installation video, please visit:
https://www.youtube.com/c/WavlinkOfficial

名称： WN530HG4说明书WAVLINK-E1	
成品尺寸： 85X125MM	展开： 595X125MM
材质工艺： 105g铜板+4C正反双面印刷+折叠	
修改时间：	
备注：	